

NUNN DESIGN COLLAGE SHEETS

Visit our website to find more inspiration and tutorials! • www.nunndesign.com

Step 1: The Nunn Design Collage Sheets are designed to fit perfectly in the Nunn Design Bezel Findings. Using a pair of scissors, cut along the outside edge of the image. Place the cut image inside the Nunn Design Bezel to double check the fit. Make sure that your image is flush to the sides of the bezel and at a 90-degree angle. If the image is coming up along the sidewalls, there is a great potential for air getting trapped. Air that is trapped will surface once you pour resin over the image.

Step 2: Remove your cut collage image from the Nunn Design Bezel. Use a Q-Tip and rubbing alcohol to clean the inside of your bezel. This helps ensure that the inside surface is oil and dirt free.

Step 3: Apply a thin coat of Nunn Design Glue onto the base of the bezel. Place your collage image into the wet glue. Press firmly with a cotton swab in the center of the image. In a circular motion burnish the image to the base of the bezel. If you applied a lot of glue onto the base of the bezel, you may have some excess coming up along the side edges of the image. Use a toothpick to clean up the excess glue.

Step 4: Using a toothpick, make sure that the collage sheet is fully adhered to the bottom of the bezel and not creeping up along the sidewalls of the bezel. You should have a 90-degree angle on all sides. No paper should be creeping up the sidewalls as this could cause air to get trapped and result in discoloration and bubbles when the resin is poured.

Step 5: It is important to create a strong barrier between the image and the Nunn Design Resin. If you don't create a strong barrier with Nunn Design Glue, the Nunn Design Resin can run the ink in the image and absorb into the paper causing the image to darken. To create the barrier and protect the image, use a clean and dry brush. Paint on a coat of Nunn Design Glue over the full image. Allow glue to dry overnight before mixing and pouring the Nunn Design Resin.

Step 6: Now you are ready to apply your Nunn Design Resin.

**NUNN DESIGN**[®]

